Software Reference Manual for the SEGA Mark III Console

The Sega Mark III Game Console	. 3
The CPU	. 4
Reset	
Interrupt System	
NMI	
INT	
The Video Display Processor (VDP)	6
Video RAM Organization	. 6
Color	. 6
Background System	. 7
Scroll Inhibit Bits	. 7
Sprites	. 8
Sprite Attribute Table	. 8
Sprite Attribute Table Organization	. 9
Sprite/Background Display Priority	.10
Color RAM	.10
Character Patterns	.10
An Example Character Pattern	.11
VDP Registers	.12
Read VDP RAM	.12
Write VDP RAM	.12
Write VDP Register	.13
Write VDP Color RAM	.13
Color RAM Addresses	.14
VDP Register Updates	.14
VDP Register Description	.15
Register 0 - VDP Control	.15
Register 1 - VDP Control	.15
Register 2 - Screen Map Base Address	.16
Register 3	.16
Register 4	.16
Register 5 - Sprite Attribute Table (SAT) Base Address	.16
Register 6 - Sprite Pattern Base Address	.17
Register 7 - Border Color	.17
Register 8 - Horizontal Scroll	.17
Register 9 - Vertical Scroll	.17
Register 10 - Raster Line Interrupt	18
The Memory Management System	
System RAM	
Memory Enables	
Memory Selection at Power-On	
Memory Maps	
32 Kilobytes	
128 Kilobytes	
The Cartridge Header	.22

# Table of Contents

The Input/Output System	23
Input Ports Bit Assignments	24
How the Gun Works	25
How the Trackball Works	
The Programmable Sound Generator (PSG)	27
Tone Generator Frequency	
Noise Generator Control	
Attenuators	
Appendix A - VDP Registers	
Appendix B - Input/Output Ports	
Appendix C - Sample Code to Read Gun	
Appendix D - Sample Code to Read TrackBall	
Appendix D - Sample Code to Read TrackBall Developer's Notes	
Developer's Notes	
Developer's Notes Z80 Memory Map	
Developer's Notes Z80 Memory Map Memory Control Registers	
Developer's Notes Z80 Memory Map Memory Control Registers	
Developer's Notes Z80 Memory Map Memory Control Registers 4M Bit ROM Z80 Address \$0000 - \$03FF	
Developer's Notes Z80 Memory Map Memory Control Registers	
Developer's Notes Z80 Memory Map Memory Control Registers	
Developer's Notes Z80 Memory Map Memory Control Registers	

# The Sega Mark III Game Console

This manual describes the SEGA Mark III game console hardware. The manual is divided into five sections:

- The CPU.
- The Video Display Processor (VDP).
- The Memory Management System.
- The Input/Output System.
- The Programmable Sound Generator (PSG).

Each section begins with a general description, followed by a detailed description of every control bit. Several pictorial diagrams at the back of the manual tie together all of the concepts described in the manual. If you wish to see how a particular feature fits into the total system, refer to these back pages

# HEADINGS

Important topics inside each section is marked as above with a "heading". This allows quick scanning for specific items of interest.

# FORWARD REFERENCES

In some sections it is impossible to describe the system without making references to technical details described further forward in the manual. For example you will find reference to "Sprite Interrupts" in the CPU section, before the notion of a sprite is discussed in the VDP section.

For this reason you might find it helpful to browse the first parts of each section to get a feel for the total system before diving into the detailed descriptions.

The system will hereafter be referred to as the "Mk3".

# THE CPU

The Mk3 uses a Z80A microprocessor, clocked at 3.58 MHz.

The implementation of Z80 features as they pertain to the Mk3 are described in this section.

### RESET

The Z80A executes a RESET cycle when the base unit is turned on. This is the only Z80A reset mechanism implemented.

The momentary RESET button on the console does not control Z80A reset; it is attached to an input port for software polling.

### **INTERRUPT SYSTEM**

The Mk3 implements two of the Z80 interrupts, the Non-maskable Interrupt (NMI), and the Maskable Interrupt (INT).

# NMI

The NMI pin is connected to the console "PAUSE" button. Pressing this button causes the Z80 to execute a Restart instruction at location \$66. This acts as a simple subroutine call: the PC is pushed onto the stack and a jump to \$0066 is performed.

This interrupt is "edge-triggered", which means that if the PAUSE button is held down, you will get a single interrupt only.

**NOTE:** The last instruction of your NMI routine must be "RETN", Return from Non-Maskable Interrupt.

The PAUSE button is for the exclusive use of your program; you must set up the transfer of control at \$0066 to your PAUSE routine.

The most common PAUSE routine will toggle a software "pause" flag and turn off the sounds if this flag has just been set. The INT routine, which is periodically activated, then checks the condition of the pause flag and does no processing if it is set (it loops on the pause flag).

This method allows the pause feature to be implemented without turning the interrupts off and on (with a DI and later an EI instruction). This DI-EI combination can cause a spurious interrupt in the Z80.

The NMI cannot be inhibited.

# INT

This interrupt is enabled with an "EI" instruction, and disabled with a "DI" instruction.

The Mk3 hardware supports the "mode 1" interrupt only. The boot

ROM executes the "IM 1" instruction at power-on.

In mode 1, activating the Z80A INT pin causes a Restart instruction to be executed at location \$38 if interrupts are enabled.

This interrupt can be activated by two events in the VDP chip:

- 1. Vertical Blanking Interval.
- 2. Horizontal Line Counter.

Here is a skeleton program for an Interrupt response routine:

```
(at $0038)
       JP
             INT
       •
       .
INT:
       PUSH AF
             A,(OBFH)
       IN
       .
       POP
             AF
       ΕI
       RET
```

The first step is to save the working registers and flags. Other "PUSH" instructions should be added for any registers your interrupt routine will use.

Reading the I/O part at \$BF does two things. First, it clears the interrupt request line from the VDP chip. Second, it provides VDP information as follows:

```
bit 7 --- 1: VBLANK Interrupt, 0: H-Line Interrupt [if enabled].
bit 6 --- 1: 9 sprites on a raster line.
bit 5 --- 1: Sprite Collision.
bits 4-0 (no significance).
```

The VDP VBLANK and H-Line interrupts are enabled with the IE and IE1 bits in VDP registers 0 and 1, as shown in the following chart:

#### **Interrupt Enable Bits**

 
 IE (R1 bit 5) IE1 (R0 bit 4)
 Interrupt Source

 0
 1

 H-Line Interrupt

 1
 1 1

H-Line Interrupt only. Both H-Line and VBLANK.

When an INT is accepted, the interrupt system is turned off, exactly as if a "DI" instruction had been executed. Thus, the code to exit from an interrupt routine should restore the registers, execute an "EI" instruction, and return.

# THE VIDEO DISPLAY PROCESSOR (VDP)

The Mk3 uses an advanced video controller chip called the VDP (Video Display Processor). The VDP is a Sega designed custom chip whose architecture resembles an enhanced TMS9918A.

The screen resolution of the VDP is 256 pixels horizontal, and 192 pixels vertical. A pixel can be shown as one of sixteen colors, selected from a palette of 64 different colors.

16 Kilobytes of RAM are dedicated to the video system. This RAM (called the video RAM) is attached directly to the VDP chip, and does not appear in the Z80 memory space. The Z80 reads and writes the Video RAM through VDP registers.

The VDP implements two independent graphic systems, a background system and a sprite system.

#### VIDEO RAM ORGANIZATION

The 16 Kilobyte Video RAM is divided into three sections:

- 1. A 1792 byte screen map. This map determines the placement of character cells (sometimes known as "tiles") on the background screen's 32 by 24 grid.
- 2. A 256 byte sprite attribute table. This table sets the X-Y coordinates and character number of up to 64 moveable objects, or sprites.
- 3. A 14,336 byte character generator. These are 8 by 8 pixel character patterns for the background, and/or 8(h) by 8(v) or 8(h) by 16(v) pixel character patterns for the sprites.

32 bytes define a single 8 by 8 pixel character. The character generator portion of the Video RAM thus is capable of defining up to 448 characters.

The placement of the three Video RAM sections is controlled by registers in the VDP. As we'll see, you have some choice over where they appear in the 16K Video RAM memory map.

# COLOR

The attribute of color is carried in the character patterns in the character generator portion of the Video RAM. Each pixel in the character pattern contains 4 bits of information. A choice of sixteen colors is thus available for every pixel.

The sixteen available colors are not fixed. they are stored in a Color RAM inside the VDP chip. The Color RAM is organizeed as 32 6-bit values. The six bits provide four levels (2 bits) of red, green, and blue.

Note that 32 color values represent twice the addressing capability of the 4-bit pixels. Other VDP control bits allow selection of the 16 value color table from either the first half or the second half of the Color RAM.

# **BACKGROUND SYSTEM**

The background system is composed of "characters" which are eight pixels high and eight pixels wide. The screen is organized as 768 visible characters: 32 horizontal by 24 vertical.

An additional 4 character rows exist below the 24 visible vertical rows. These additional rows are useful for scrolling new background information upwards onto the screen.

2048 bytes of the video RAM function as the screen map. This map defines the screen positions of 896 characters (768 visible).

At every character position, there is a 16-bit (2 byte) word which describes the following:

- 1. Which of 512 characters to display at the character position (9 bits).
- 2. Whether or not to flip the character horizontally or vertically (2 bits).
- 3. Which of two sets of 16 colors to use for the character (1 bit).
- 4. Whether sprites obscure the background, or vice versa (1 bit).
- 5. Three uncommitted bits, useful for software flags (3 bits).

The visible screen map occupies 1536 bytes of video RAM (768 characters, two bytes per character).

The nonvisible four rows of characters below the visible screen occupy 256 bytes (128 characters, two bytes per character).

This leaves 256 bytes of unused memory at the highest address of the 2048 byte screen map RAM. These 256 bytes are normally used to store the Sprite Attribute Table.

This memory could also be used to store eight character patterns, if the Sprite Attribute Table is located elsewhere. If the screen map is placed at \$3800 (the usual case), the character numbers for the unused 256 bytes of screen map RAM are \$1F0 through \$1F7.

# SCROLL INHIBIT BITS

The background screen can be scrolled in one pixel increments both horizontally and vertically. Two "scroll inhibit" bits allow you to inhibit scrolling in two screen areas:

If HSI (Horiz Scroll Inhibit) is set to 1, the 2 character high horizontal strip at the top of the screen does not scroll.

If VSI (Vert. Scroll Inhibit) is set to 1, the vertical band of 8 characters at the right edge of the screen does not scroll.

This feature simplifies the placement of score information at the top or right side of the screen. When the background screen playfield scrolls, the scores remain in place if the scroll inhibit bits have been set.

# SPRITES

A sprite is an easily movable object. The VDP provides 64 independent sprites. A control bit controls the size of all sprites: 0 for an 8H by 8V spite, 1 for an 8H by 16V sprite.

Each sprite uses a three byte entry in a Sprite Attribute Table (in Video RAM) to set it's vertical and Horizontal position, and to select one of 256 characters to be displayed for the sprite.

A VDP control bit (Sprite Shift, bit 3 of R0) shifts all sprites 8 pixels to the left. This allows sprites to smoothly scroll off the left edge of the screen.

Sprite and background characters are drawn from the same "pool" of character patterns in video RAM. Thus sprites have the same color capabilities as background characters: 16 colors at a time from a choice of 64 colors.

Sprite colors are always taken from the second group of 16 colors in the color RAM.

Sprites do not scroll when the background scene is scrolled.

Sprites can be placed over or under other sprites. Sprites can also appear over or under characters in the background scene.

Up to eight sprites can occupy a single horizontal raster line. A VDP status register bit is provided to alert you when nine or more sprites are positioned on the same line. A horizontal raster line containing nine or more sprites is not displayed properly.

Another VDP status register bit indicates that two sprite patterns touched (collided).

# SPRITE ATTRIBUTE TABLE

A 256 byte section of Video RAM functions as the Sprite Attribute Table. VDP register R5 is usually set to \$FF to position the Sprite Attribute Table at \$3F00, the last 256 bytes of Video RAM.

The Sprite Attribute Table is organized as shown on the table on the next page.

#### **Sprite Attribute Table Organization**

#### Address Attribute

3F00 3F01 3F02 3F03 3F04 3F05 3F06 3F07	<pre>vpos #0 vpos #1 vpos #2 vpos #3 vpos #4 vpos #5 vpos #6 \$D0 (terminator)</pre>
3F3E	
3F3F	vpos #63
3F40 3F7F	64 unused bytes. [Can put two 32 byte character patterns here and address as char's \$1FA and \$1FB].
3F80 3F81 3F82 3F83 3F84 3F85 3F86 3F86 3F87	hpos #0 char code #0 hpos #1 char code #1 hpos #2 char code #2
3FFE 3FFF	hpos #63 char code #63

The special code \$D0 is placed as a vertical position code to tell the sprite hardware to stop searching the list for sprites. All sprites which occur after the \$D0 entry are disabled.

When two sprites overlap, the higher numbered sprite will be displayed on top. The overlap priority is thus set by the positions of the sprites in the table.

The horizontal position bytes locate the upper left corner of the sprite at one of 255 horizontal coordinates on the screen.

An hpos=0 puts the sprite on the left column of the screen (left 8 pixels). An pos=255 puts the sprite at the last pixel column; only the left column pixels of the sprite are seen and the other 7 columns in the sprite pattern are blanked.

This makes it easy to smoothly scroll a sprite off the **right** edge of the screen.

Setting a VDP Sprite Shift bit (R0, bit 3) shifts all sprite patterns eight pixels to the left. This allows sprites to be smoothly scrolled off the **left** edge of the screen.

If smooth appearing and disappearing of sprites is desired on **both** edges of the screen, another VDP control bit (R0, bit 5) can be set to 1 to blank the left column of characters.

Thus if R0 bit 3 is set to 0 (no shift left), and R0 bit 5 is set to 1 (blank left column), the screen is reduced to 31 character columns, and sprites enter and leave the screen smothly. The left edge is handled by the fact that sprite hpos=0 puts the sprite in the left column, which is blanked in this mode.

# SPRITE/BACKGROUND DISPLAY PRIORITY

Sprites can appear in front of or behind the background scene. This is controlled by bit 12 of the 16bit background character code. If this bit is set to 0, all sprites appear over the background. If this bit is set to 1, background colors #1-15 appear over the sprites. Background color #0 always appears under the sprites.

# COLOR RAM

The VDP chip contains a color RAM of 32 6-bit values. These values are formatted as "write only" 8-bit bytes:

+	+	+	+	+	+	+	+	F.
X	X	B1	в0	G1	G0	R1	R0	
+	+ •	+	+	+	+	+	+	÷

where R1:R0, G1:G0 and B1:B0 define four intensities for red, green, and blue as follows:

R,G,B-0	Intensity
0	Off
1	1/3
0	2/3
1	3/3 (brightest)
	<b>R,G,B-0</b> 0 1 0 1

The color RAM is organized as two banks of 16 colors each. Colors are selected from either bank with a four bit color code.

# **CHARACTER PATTERNS**

The actual dot patterns for screen images are called characters. Character patterns are used by both the background system and the sprites.

Every character is made up of 32 bytes. These bytes are orgaized as eight 4 byte groups, where each 4 byte group forms one row of pixels.

Four bits are required to select 16 colors. These bits come from corresponding bits in the four planes. The table on the next page shows a 32 byte character patern. "0's" are shown as periods for clarity.

# An Example Character Pattern

#### Byte b7 b6 b5 b4 b3 b2 b1 b0

0 1 2 3	1 1	1 1	1 1	1 1	1 1	1 1	1 1	1 1	c0 c1 c2 c3	FIRST PIXEL ROW: '0101' = color #5
4 5 6 7	1 1	1 1							c0 c1 c2 c3	SECOND PIXEL ROW: '1100' = color #12, '0000' = color #0.
8 9 10 11	1 1	1 1							c0 c1 c2 c3	THIRD PIXEL ROW
12 13 14 15	1 1	1 1	• • •	• • •	• • •	• • •	• • •		c0 c1 c2 c3	FOURTH PIXEL ROW
16 17 18 19	1 1	1 1							c0 c1 c2 c3	FIFTH PIXEL ROW
20 21 22 23	1 1	1 1							c0 c1 c2 c3	SIXTH PIXEL ROW
24 25 26 27	1 1	1 1							c0 c1 c2 c3	SEVENTH PIXEL ROW
28 29 30 31	1	1	1	1	1	1	1	1	c0 c1 c2 c3	EIGHTH PIXEL ROW '0010' = color #2

This pattern represents a multicolor letter "C".

The top section is color #5 (reading corresponding bits from MSB to LSB, 0101).

The vertical section is color #12 (1100).

The bottom section is color #2 (0010).

Which colors these represent depends on the values stored in color RAM locations 2, 5 and 12.

**NOTE:** the 8 by 8 character background color is #0 (0000).

#### **VDP REGISTERS**

The VDP is controlled by eleven internal 8-bit registers. This section describes the method by which the Z80A accesses these registers, and then discusses the function of the individual registers.

The Z80 "sees" the VDP chip through two I/O port locations, \$BE and \$BF. I/O location \$BF is the COMMAND register for a write, and the STATUS register for a read.

I/O port \$BE is the read/write DATA register.

The Command Register is written twice in succession for all command operations; the data register may be read or written any number of times in succession, depending on the operation.

Because the command register is sequence sensitive, requiring a **pair** of out bytes per operation, a DI instrucion should precede command register updates. This prevents, for example, an interrupt service routine that reads the VDP status register from disrupting the two byte synchronization.

# There is a timing constraint for accessing the VDP chip.

The VDP chip cannot process data any faster than the following rates:

16 Z80A T-States during VBLANK 29 Z80A T-States during active video.

This means that you should never issue two consecutive OUT or IN instructions to the VDP; they should be separated by at least a NOP instruction.

This constraint applies to Video RAM and Color RAM as well as the internal registers.

A two bit mode field in bits 7 and 6 of the second COMMAND byte determines one of four operations:

b7 b6	Operation
0 0	Read 16 Kbyte VDP RAM
0 1	Write 16 Kbyte VDP RAM
1 0	Write VDP Register
1 1	Write Color RAM

To set up for the first two operations, read/write Video RAM the two COMMAND bytes have the following format:

# **Read VDP RAM**

First byte	++		++	+	+-	+	+	+
written to \$BF	A7	Аб	A5	A4	A3	A2	A1	A0
	+		+	+·	+-	· + ·	+	+
Second byte	0	0	A13	A12	A11	A10	A9	A8
writen to \$BF	++		++	+	+-	+	+	+

#### Write VDP RAM

First byte written to \$BF	A7	A6	A5	A4	A3	A2	A1	++   A0
Second byte writen to \$BF	0	1	A13	A12	A11	A10	A9	

After the COMMAND bytes have been output, data can be read at Input Port \$BE or written at Output Port \$BE.

The VDP has an address auto-increment feature. Once the Video RAM starting address has been loaded, the data (I/O port \$BE) may be repeatedly accessed, and the address will automatically increase by one byte for every access.

NOTE: The autoincrement feature works only with all reads or all writes. Changing from read to write or vice versa requires two writes to the command register to reselect the mode.

The COMMAND register format for writing a VDP register (they are write-only) is shown below:

#### Write VDP Register

First byte written to \$BF	d7   d6	d5   d4	d3   d2	++   d1   d0
Second byte writen to \$BF	1   0	0 0	r3   r2	r1   r0   -++

The register number is r3-r0, and ranges from 0 through 10 (\$00 through \$0A). The data to be written to the register is d7-d0.

For the "write register" operation only, there is no write to the DATA register at \$BE, since the data (d7-d0) is contained in the first byte of the COMMAND byte pair.

The final command mode allows writing color values to the write-only VDP Color RAM.

# Write VDP Color RAM

First byte	+	-+	+	+	+ ·	+ •	+ +	·+	-
written to \$BF	0	0	0	A4	A3	A2	A1	A0	
		-+	•						
Second byte	1	1	0	0	0	0	0	0	
writen to \$BF	+	-+	+	+	+	+	+1	+	•

After loading this pair of bytes to the COMMAND register, the color RAM data is written to Output Port \$BE in the following format:

Where b1-b0 set four intensities for blue, g1-g0 set four intensities for green, and r1-r0 set four intensities for red.

As with the Video RAM, repeated writes to Output Port \$BE automatically increment the Color RAM address. Color RAM addresses are mapped as shown on the next page.

Color RAM Ad	ldress	Color Number	r -	
00001 00010 0011 00100 00101 00110 01000 01001 01010 01011 01101 01101	(\$01) (\$02) (\$03) (\$04) (\$05) (\$06) (\$07) (\$08) (\$09) (\$08) (\$09) (\$00) (\$00) (\$0D) (\$0E)	Bank1, Color Bank1, Color Bank1, Color	<pre>c 1 c 2 c 3 c 4 c 5 c 6 c 7 c 8 c 10 c 11 c 12 c 13 c 14</pre>	colors can be taken from either the first group of sixteen or the second group of
10001 10010 10011 10100 10110 10111 11000 11001 11010 11101	(\$11) (\$12) (\$13) (\$14) (\$15) (\$16) (\$16) (\$17) (\$18) (\$19) (\$1A) (\$1B) (\$1B) (\$1D) (\$1E)	Bank2, Color Bank2, Color	<pre>c 1 c 2 c 3 c 4 c 5 c 6 c 7 c 8 c 10 c 11 c 12 c 13 c 14</pre>	[Note: Border colors and sprite colors are taken from this second group of sixteen colors]

The command register has one additional function. When it is read with an IN (\$BF) instruction, it functions as an interupt status register, and also clears interrupt requests from the VDP chip.

# **VDP REGISTER UPDATES**

In general, all VDP updates should be done while the TV's video signal is blanked. If operations that affect the screen appearance are not done during screen blanking, the screen will appear to have "noise" in the picture.

Your program can detect horizontal and vertical blanking intervals using the interrupt system and VDP flag bits. This capability is discussed in the CPU section.

It is not necessary to synchronize VDP initialization with blanking intervals, since the screen can be blanked prior to the setup operations, and then turned on when the initialization is complete.

# **VDP REGISTER DESCRIPTION**

# <u>Register 0</u> <u>Register 1</u>

R0 and R1 set the VDP display and interrupt mode.

R0:	b7	VSI	Vertical Scroll Inhibit (right 8 char columns). 0: Scroll along with background. 1: Fixed (no scroll).			
	b6	HSI	Horizontal Scroll Inhibit (top 2 char rows). 0: Scroll along with background. 1: Fixed (no scroll).			
b5 LCB Left Column Blank. 0: Normal Display. 1: Blank left char column (border color						
	b4	IE1	Interrupt Enable.			
	b3	SS	Sprite Shift. 0: Normal sprite position. 1: Shift all sprites 8 pixels to the left.			
	b2	1	[Always set this to 1].			
	b1	1	[Always set this to 1].			
	b0	ES	External Sync. [Always set this to 0].			
R1:	b7	1	[Always set this to 1].			
	b6	DIS	Display ON. 0: Blank whole screen. 1: Normal video.			
	b5	IE	Interrupt Enable.			
	b4	0	[Always set this to 0].			
	b3	0	[Always set this to 0].			
	b2	0	[Always set this to 0].			
	b1	SZ	Sprite Size. 0: All sprites are 8 by 8. 1: All sprites are 8 by 16.			
	b0	0	[Always set this to 0].			

The two bit interrupt control field is defined as follows:

IE	IE1	Enabled Interrupt:
0	1	Raster Line.
1	1	VBLANK and Raster Line.

## **Register 2**

R2 sets the base address for the screen map. It positions the 2048 screen map to one of eight starting addresses, on 2048 byte boundaries, according to the following table:

R2 Value	Screen Map Base Address
\$FF	\$3800 < Normal Setting
\$FD	\$3000
\$FB	\$2800
\$F9	\$2000
\$F7	\$1800
\$F5	\$1000
\$F3	\$0800
\$F1	\$0000

The normal setting for R2 is \$FF, which positions the base address at \$3800, the highest-addressed 2 KByte section of the 16 KByte Video RAM.

#### **Register 3**

R3 should always be set to \$FF.

### **Register 4**

R4 should always be set to \$FF.

### **Register 5**

R5 controls the base address for the Sprite Attribute Table. This 256 byte table can be positioned at one of 64 starting addresses in Video RAM.

The base address is formatted in R5 as follows:

	+	+	+	+	+	+ •	++	++
R5:	1	A13	A12	A11	A10	A9	A8	1
	+	+	++	+	+ •	+ •	+ +	++

The normal setting for R5 is \$FF, which positions the Sprite Attribute Table at \$3F00. When R2 is \$FF, placing the screen map at \$3800, and R5 is \$FF, the unused top 256 bytes of screen map memory is occupied by the 256 byte Sprite Attribute Table.

# <u>Register 6</u>

R6 sets the base address for the sprite patterns. Only two values are valid for R6:

R6 Value	Sprite Patterns				
\$FB \$FF \$FF	First 8K of Video RAM < Normal Value Second 8K of Video RAM				

The preferred location for the sprite patterns is in the first 8K of video RAM, since the full 8192 bytes are available for patterns. In the second 8K, 2048 bytes are lost to the screen map and Sprite Attribute Table. Thus 256 sprite patterns can be stored in the first 8K, but only 192 sprite patterns can be stored in the second 8K.

# **Register 7**

R7 sets the border color. The border color is taken from the **second** bank of colors in VDP Color RAM.

R7: | 1 | 1 | 1 | 1 | C3 | C2 | C1 | C0 |

# **Register 8**

R8 sets the horizontal scroll value for the background scene. A value of \$00 produces no scrolling. A value of \$01 moves the background scene one pixel to the left, and moves the leftmost column of pixels to the rightmost column (the scrolling "wraps around").

Higher value of R8 "rotate" the screen horizontally to a maximum of 255 pixels for a value of \$FF. Note that horizontal scrolling resembles a rotating vertical cylinder, with graphic information disappearing from the left side of the screen and reappearing on the right side of the screen.

### **Register 9**

R9 sets the vertical scroll value for the background scene. A value of \$00 produces no scrolling. A value of \$01 moves the background scene one pixel upward. The vertical scrolling resembles a rotating horizontal cylinder, but the "wrap around" point is not at the screen edge, as with horizontal acrolling. Rather, it is at the 28th character row. (Remember that the screen is organized as 28 character rows, with the top 24 displayed on the screen).

Register 9 is latched in vertical blanking.

### Register 10

R10 controls the Raster Line Interrupt.

The TV beam sweeps out horizontal lines (called raster lines) from left to right, moving from the top to the bottom of the screen. The visible picture contains 192 of these raster lines.

At the end of each raster line there is a brief blanking interval (HBLANK) in which the TV beam is turned off as the beam retraces from the right side to the left side of the screen. This HBLANK interval last approximately 10 microseconds.

It is desireable to receive an interrupt just after a selected raster line has been displayed. For example, you might want to change a color value after the beam has swept out the top half of the screen. In this case you would want to know when the 95th raster line has completed.

R10 allows you to do this. If you load R10 with 94, a Raster Line Interrupt Request will be generated every time the 95th horizontal line finishes it's scan.

The value loaded into R10 should be one less than the raster line you wish to "trigger" the interrupt.

The Raster Line Interrupt continues to generate interrupt requests as the beam sweeps the screen. The table on the next page shows the settings of R10 and the raster lines that generate interrupt requests at HBLANK time:

R10 Value	Interrupt Requests at these HBLANK times
\$C0-\$FF	None
\$00	1,2,3,4,5,191
\$01	2,4,6,8,10,190
\$02	3,6,9,12,189
\$03	4,8,12,16,188
(etc)	(etc)

There are two special cases: \$FF turns off the interrupt requests, and \$00 gives a Raster Line interrupt request for every horizontal line.

There is a one interrupt delay between loading R10 and having the value take effect. For example, if you set R10 for line 20, and respond to the interrupt by resetting R10 to 150, the very next Raster Line Interrupt will occur at 20, and all subsequent ones will occur at 150.

The VDP registers are initialized at power on to the following values:

R0	\$36	; mode
R1	\$A0	; mode
R2	\$FF	; Screen Map Table Base
R3	\$FF	; (Always \$FF)
R4	\$FF	; (Always \$FF)
R5	\$FF	; Sprite Table Base
R6	\$FB	; Sprite Pattern Table Base
R7	\$00	; Border color #0
R8	\$00	; Scroll-H
R9	\$00	; Scroll-V
R10	\$FF	; H-line interrupt (\$FF=OFF)

# **MEMORY MANAGEMENT**

The Mk3 base unit contains 8 kilobytes of ROM and 8 Kilobytes of RAM. Game program ROM is plugged into the unit by using one of two slots.

The front slot accepts a slim cartridge that resembles a credit card. The present capacity of this card is 32 Kilobytes. A 128 Kilobyte card is in the works.

The top slot accepts a more conventional plastic-cased game cartridge. 128 Kilobyte cartridges are now in production. 256 Kilobyte and larger cartridges are in the works.

The Z80A processor is capable of addressing 64 kilobytes of memory. Because the added game cartridge memoy can exceed 64 Kilobytes, a simple memory management system is implemented in the Mk3.

When the Mk3 is turned on, the memory map contains an 8 kilobyte ROM at \$0000, and an 8 Kilobyte RAM at \$C000.

# SYSTEM RAM

The RAM is mapped into two places, \$C000-\$DFFF and \$E000-\$FFFF. This RAM is used for Z80A stack and scratchpad use.

The top eight locations of RAM are reserved for memory management control registers, and should not be used by a game program.

For future compatibility, the RAM should be addressed at \$C000-\$DFFF. The stack should be placed at \$DFF8.

# **MEMORY ENABLES**

Output port \$3E controls the memory enables. Individual bits in this port enable the System ROM, System RAM, Card Slot, Cartridge Slot, and External Slot. (The external Slot is not presently used).

Output port \$3E has the following format:

OUT (\$3E):	
bit O	don't care
bit 1	don't care
bit 2	0: enable joysticks 1: disable joysticks
bit 3	0: enable base unit 8K ROM 1: disable base unit 8K ROM
bit 4	0: enable internal 8K RAM 1: disable internal 8K RAM
bit 5	0: enable card ROM 1: disable card ROM
bit 6	0: enable cartridge ROM 1: disable cartridge ROM
bit 7	0: enable external port 1: disable external port

# MEMORY SELECTION AT POWER-ON

When the system is turned on, the Z80A begins executing code at location \$0000 in the resident 8 Kilobyte ROM. This ROM code performs the following steps:

- 1. The system is initialized.
- 2. A small program is copied from ROM into the RAM (at \$C700).
- 3. The program jumps to \$C700 to execute this prgram.
- 4. All of the system ROM spaces are disabled. This is why the program is copied to RAM and run there--the ROM spaces can then be checked one by one.
- 5. The ROM spaces are individually enabled and checked for the presence of memory. They are checked in the following order:
  - A. Front card slot.
  - B. Top cartridge slot.
  - C. External (rear) slot.
- 6. If memory is detected in any of these three slots, the slot is enabled and the Z80A executes a jump to location \$0000.
- 7. If no memory is detected, the console ROM is eneabled and an "Insert a cartridge" message is put on the screen.

Notice that if both the card and cartridge are plugged in, the card will be enabled because it is checked first.

A game program is written as a completely self-contained Z80A application program with origin \$0000. A game program must take care of all system "housekeeping", for example setting up the interrupt vectors.

# Once a game is running, there is no access to the boot ROM.

## **MEMORY MAPS**

The figures on the following page show memory maps for two presently defined memory sizes: 32 Kilobytes, and 128 Kilobytes.

Figure M-1 shows the Z80A memory map at power-on.

# **32 KILOBYTES**

Figure M-2 shows the Z80A memory map for the 32 Kilobyte card. This is the simplest case: 32 Kilobytes starting at location \$0000.

# **128 KILOBYTES**

Figure M-3 shows the memory map for a 128 Kilobyte cartridge. (This is refered to in the Sega literature as a "Mega"(bit) cartridge).

As with the 32 KByte memory, there is a contiguous section of ROM in the bottom half of Z80A memory. This section is always available to the Z80A.

Additionally, there are six banks of 16 Kilobyte ROM at memory addresses \$8000-\$BFFF. Only one of these banks is available to the Z80A at a time. Whenever one is selected, the other five are inactive.

Which of the six banks is switched into the Z80A memory space is controlled by a register at memory location \$FFFF.

The Bank Control Register has the following format:

\$FFFF 0 0 0 0 0 b2 b1 b0

The banks are numbered from 2 through 7 (b2:b1:b0).

Although this write-only register exists in the memory cartridge, writes to the register are duplicated in the RAM at \$FFFF. This means that the bank select register appears to be read/write, even though what is actually read is the RAM image of the register, rather than the contents of the register itself.

# THE CARTRIDGE HEADER

The presence of a cartridge is tested by checking for specific information in ROM. This information must be correct for the cartridge to be recognized.

Normally, Sega will add the correct information to the cartridge before production. The information below is given for reference only.

The header format is as follows (addresses shown for 32 KByte and larger cartridges):

# <u>At \$7FF0:</u>

The string, "TMR SEGA " [54,4D,52,20,53,45,47,41,20,20]

# At \$7FFA-\$7FFB

A 16-bit checksum for the ROM (low-hi order). \$7FFA and \$7FFB are not included in this checksum.

# At \$7FFC-\$7FFD

A 16-bit serial number, assigned by Sega.

# <u>At \$7FFE</u>

A software revision number byte.

# <u>At \$7FFF</u>

ROM Size code:

\$4A	8K		(header	at	\$1FF0)
\$4B	16K		(header	at	\$3FF0)
\$4C	32K				
\$4D	48K				
\$4E	64K				
\$4F	128K	(1M)			
\$40	256K	(2M)			

# **INPUT/OUTPUT (I/O) PORTS**

Eight I/O ports are used by the Mk3:

Port	Direc	Function
\$3E	out	Memory Enables
\$3F	out	Joystick port control
\$7E	in	Gun Spot (vertical)
\$7F	in out	Gun spot (horizontal) Programmable Sound Generator (PSG)
\$BE	i/o	VDP Data Register
\$BF	i/o	VDP Command/Status Register
\$DC	in	Joystick port
\$DD	in	Joystick port

Port \$3E is described in the MEMORY MANAGEMENT section.

Port \$7F is described in the PSG section.

Ports \$BE and \$BF are described in the VDP section.

The remaining ports deal with the attached controls, and are described in this section.

Ports \$DC-\$DD are connected to the two 9-pin connectors on the front of the game console. Although these ports are called "joystick ports", there are actually three devices that can be plugged into the front connectors:

- 1. The joystick controls which include a joystick and two push buttons.
- 2. The gun.
- 3. A "Sports Pad" that consists of a trackball and two push buttons.

# INPUT PORTS BIT ASSIGNMENTS

The bits of input ports \$DC and \$DD are used for the joystick assembly, gun, and Sports Pad (Trackball). These two ports work in conjunction with port \$3F, which sets the direction of four of the bits, and provides two strobe bits for the Sports Pad. The following table shows how the three ports are interpreted for the joystick and gun options. All bits shown are inputs.

Port	Bit	Joystick	Gun
\$DC	0	P1-up	
\$DC	1	P1-down	
\$DC	2	P1-left	
\$DC	3	P1-right	
\$DC		P1-SW1	Pl Trigger
\$DC	5	P1-SW2	
\$DC	6	P2-up	
\$DC	7	P2-down	
\$DD	0	P2-left	
\$DD		P2-right	
\$DD		P2-SW1	P2 Trigger
\$DD		P1-SW2	
\$DD		RESET*	RESET*
\$DD			
\$DD	6		Pl Light Pulse
\$DD	7		P2 Light Pulse
\$3F	0	1	1
\$3F		1	Pl Latch Enable
\$3F		1	1
\$3F		1	P2 Latch Enable
\$3F		1	1
\$3F		1	1
\$3F		1	1
\$3F	7	1	1

# HOW THE GUN WORKS

The gun contains a lens and photocell which "sees" a spot on the TV screen. This spot is circular, and increases in diameter as the gun's distance from the screen increases.

When the TV beam reaches the area at which the gun is pointed, two things happen:

- 1. A negative pulse of approximately 20-30 microseconds is generated on port \$DD bit 6 (Player 1) or port \$DD bit 7 (Player 2). This pulse is wide enough to allow a software loop to recognize it. The width of this pulse will vary with the game setup and TV type.
- 2. The beam position is latched into horizontal and vertical registers, which are read at input ports \$7E (vertical) and \$7F (horizontal).

The beam position can be latched either from a gun plugged into the player 1 connector, a gun plugged into the player 2 connector, or both. [NOTE: The player 1 connector is the left connector when the game console is viewed from the front].

Two bits in output port \$3F determine which gun latches the beam position. These are shown as "P1 Latch Enable" and "P2 Latch Enable" in the preceding table.

The gun reading routine usually performs the following steps.

- 1. The trigger switch is checked. Normally the gun is not checked until someone pulls the trigger. (Data is continuously available from the gun, however).
- 2. When the trigger is pulled, wait for the next VBLANK.
- 3. At VBLANK, put up an all white screen (all color bytes are \$3F). This gives enough light intensity on the screen for the gun to read any position.
- 4. During the next scan, continuously check the light pulse bit for a high to low transition. (P1 Light Pulse is at input port \$DD bit 6; P2 Light Pulse is at input port \$DD bit 7).
- 5. When the pulse is detected, read the Horizontal Position Register at \$7F and the Vertical position Register at \$7E.
- 6. Wait for a low to high transition on the Light Pulse bit. Then repeat step 5 for all active horizontal lines.
- 7. When finished with one scan, restore the screen to the normal color values.

The gun responds to a circular spot on the TV, not a single pixel. As the circular spot is "seen" by the photocell in the gun, repeated negative pulses will occur on the Light Pulse bit for several consecutive horizontal scan lines.

The horizontal values of the detected circle will, as the vertical position register increments, decrease, increase, and then stop as the left edge of the scanned circle is read by the lens in the gun.

For this reason it is advisable to do some sort of averaging and extrapolation to arrive at a center position of the scanned circle.

### HOW THE TRACKBALL WORKS

The interface to the trackball consists of six input bits and one output bit.

Trackball	dir	Player 1	Player 2
b0	in	<pre>\$DC bit 0 \$DC bit 1 \$DC bit 2 \$DC bit 3</pre>	\$DC bit 6
b1	in		\$DC bit 7
b2	in		\$DD bit 0
b3	in		\$DD bit 1
S1	in	\$DC bit 4	\$DD bit 2
S2	in	\$DC bit 5	\$DD bit 3
STROBE	out	\$3F bit 5	\$3F bit 7

Before using the trackball, the following two instructions should be executed to set the STROBE bit directions to output, and initialize the strobe signals to 1.

NOTE: these instructions are executed in the power-on initialization.

LD A,10100101b ; b1,b3 set strobe direction to output OUT (03FH),A ; b5,b7 are actual strobe bit values

The strobe signal is then used to clock in four 4-bit nibbles b3-b0, which occur in the following order:

Nibble #	Data	When STROBE is:
	b3 b2 b1 b0	
1 2 3 4	X7 X6 X5 X4 X3 X2 X1 X0 Y7 Y6 Y5 Y4 Y3 Y2 Y1 Y0	LO HI LO HI

The X,Y positions of the trackball are represented as X7-X0 and Y7-Y0. These are 8-bit counters which wrap around from \$FF to \$00.

As the ball is spun to the right, the X value increase; as it is spun to the left, they decrease. As the ball is spun upward, the Y values increase; as it is spun downward, they decrease.

The timing of the STROBE transitions is important. Here is the required sequence:

```
Program Sequence to Read Trackball
[Start with STROBE HI].
1. STROBE LO.
2. Wait 80 microseconds.
3. Read first nibble.
   STROBE HI.
4.
5. Wait 40 microseconds.
   Read second nibble.
6.
7. STROBE LO.

    8. Wait 40 microseconds.
    9. Read third nibble.

10. STROBE HI.
11. Wait 40 microseconds.
12. Read fourth nibble.
13. (done-STROBE is HI).
```

Appendix D shows working code to read the trackball each interrupt.

Sega Mk3 Hardware Reference Manual (Rev1) Page 26

# PROGRAMMABLE SOUND GENERATOR (PSG)

The PSG contains four sound channels, consisting of three tone generators and a noise generator. Each of the four channels has an independent volume control (attenuator). The PSG is controlled through output port \$7F.

# TONE GENERATOR FREQUENCY

The frequency (pitch) of a tone generator is set by a 10-bit value. This value is counted down until it reaches zero, at which time the tone output toggles and the 10-bit value is reloaded into the counter. Thus, higher 10-bit numbers produce lower frequencies.

To load a new frequency value into one of the tone generators, you write a pair of bytes to I/O locations \$7F according to the following format:

First Byte:	1	R2	R1	R0	d3	d2	d1	d0
Second Byte:	0	0	d9	d8	d7	d6	d5	d4   +

The R2:R1:R0 field selects the tone channel as follows:

R2	R1	R0	Tone Channel
0	0	0	#1
0	1	0	#2
1	0	0	#3

10-bit data is (msb) d9 d8 d7 d6 d5 d4 d3 d2 d1 d0 (lsb)

# NOISE GENERATOR CONTROL

The noise generator uses three control bits to select the "character" of the noise sound. A bit called "FB" (Feedback) produces periodic noise or "white" noise:

FB Noise Type
0 Periodic (like low-frequency tone)
1 White (hiss)

The frequency of the noise is selected by two bits NF1:NF0 according to the following table:

NF1	NF0	Noise Generator Clock Source
0	0	Clock/2 [Higher pitch, "less coarse"]
0	1	Clock/4
1	0	Clock/8 [Lower pitch, "more coarse"]
1	1	Tone Generator #3

Note: "Clock" is fixed in frequency. It is a crystal controlled oscillator signal connected to the PSG.

When NF1:NF0 is 11, Tone Generator #3 supplies the noise clock source. This allows the noise to be "swept" in frequency. This effect might be used for a jet engine runup, for example.

To load these noise generator control bits, write the following byte to I/O port \$7F:

	++-	+-	+	+-	+	+	+	+
Out (\$7F):	1	1	1	0	0	FB	NF1	NF0
	++-	+-	+	+-	+	+	+	+

# ATTENUATORS

Four attenuators adjust the volume of the three tone generators and the noise channel. Four bits A3:A2:A1:A0 control the attenuation as follows:

#### A3 A2 A1 A0 Attenuation

0	0	0	0	0 db	(maximum volume)
0	0	0	1	2 db	NOTE: a higher attenuation results
0	0	1	0	4 db	in a quieter sound.
0	0	1	1	6 db	
0	1	0	0	8 db	
0	1	0	1	10 db	
0	1	1	0	12 db	
0	1	1	1	14 db	
1	0	0	0	16 db	
1	0	0	1	18 db	
1	0	1	0	20 db	
1	0	1	1	22 db	
1	1	0	0	24 db	
1	1	0	1	26 db	
1	1	1	0	28 db	
1	1	1	1	-Off-	

The attenuators are set for the four channels by writing the following bytes to I/O location \$7F:

								+	
Tone Generator #1:	1	0	0	1	A3	A2	A1		
Tone Generator #2:	1	0	1	1	A3	A2	A1		
Tone Generator #3:	1	1	0	1	A3	A2	A1		
Noise Generator:	1	1	1	1	A3	A2	A1	A0   ++	
	+	++		+			+	+	-

# EXAMPLE

When the Mk3 is powered on, the following code is executed:

	LD LD LD OTIR (etc.	HL,CLRTB C,PSG_PRT B,4	; ;	clear table psg port is \$7F load four bytes write them
CLRTB	defb	\$9F,\$BF,\$DF	,\$F	F


This code turns the four sound channels off. It's a good idea to also execute this code when the PAUSE button is pressed, so that the sound does not stay on continuously for the pause interval.

# **Appendix A - VDP Registers**

	+	+	+	+	+	+	+	+	
	VScroll	HScroll	LEFT		Sprite				
R0		Inhibit		IE1	Shift	1	1	0	
	Bit	Bit	Blank		Bit		(M3)		
	+	+	+	+	+	+	+	+1	-
	+	+	+	+	+	+	+	++	+
	1	Screen						Sprite	
R1	1	Enable	IE	0	0	0	Size	Mag Bit	
	1	Bit		(Ml)	(M2)		8/16		
	+	+	+	+	+	+	+	+1	-
	+	+	+	+	+	+	+	++	-
					SCRN	SCRN	SCRN		\$FF
R2	1	1	1	1	BASE	BASE	BASE	1	(Screen Base
					2	1	0		at \$3800)
	+								-
	+	+	+	+	+	+	+	++	+
		ļ	ļ		ļ		ļ		
R3	1	1	1	1	1	1	1	1	ŞFF
	 +	 +	 +	 +	 +	 +	 +	 +	-
	+	+	+	+	+	+	+	++	-
R4	1	1	1	1	1	1	1	1	\$FF
	 +	 +	 +	 +	 +	 +	 +	 +	-
	+	+	+	+	+	+	+	++	-
		SAT	SAT	SAT	SAT	SAT	SAT		\$FF (SAT at \$3F00)
R5	1	BASE  5	BASE	BASE	BASE	BASE	BASE	1	SAT=Sprite Attribute Table
	 +	+	<del>"</del> +		4 +	1 +	U +	 +	- Table
	+	+	+	+	+	+	+	++	÷
DC		1	1	1	1 1	CGEN	1 1		\$FB (CG at \$0000)
R6	1	1	1	1	1	BANK 0	1	1	CGEN=Character Generataor
	 +	 +	 +	 +	 +	+	 +	 +	Generataor
	+	+	+	+	+	+	+	+	+
R7	1	1	   1			ם שת פו או	DODGED	BORDER	Border Color
K7	1 1	± 	±	±		2		0	BOIDEL COIDI
	+	, +	, +	, +	+	+	+	+	+
	+	+	+	+	+	+	+	+	ćoo waadaantal
R8	HSCROLL	HSCROLL	HSCROLL	HSCROLL	HSCROLL	HSCROLL	HSCROLL	HSCROLL	\$00 Horizontal Scroll
100	1	1			1				<
	+	+	+	+	+	+	+	+	+
	+	+	+	+	+	+	+	+4	\$00 Vertival
R9	VSCROLL	VSCROLL	VSCROLL	VSCROLL	VSCROLL	VSCROLL	VSCROLL	VSCROLL	Scroll
		6							
	+	+	+	+	+	+	+	+	-
	+	 	 	 	 	 			\$FF Horizontal
R10	HLI	HLI	HLI	HLI	HLI	HLI	HLI		Line Interrupt
	7	6	5	4	3	2	1	0	(\$C1-\$FF=Disable)
	+	+	+	+	+	+	+	++	+
	+	+	+	+	+	+	+	++	
Read Port \$BF									
(VDP STATUS)					х	x	X	X	
	(VBL) +					 +	 +	 +	-
Write Port \$BF					+++	-+++	++	+	
(VDP CONTROL)	agistor		First		Reg				
To write VDP R r3:r2:r1:r0 =					1  0  X				
			220010	-,	+++	-+++	++	+	

NOTE: First disable interrupts since VDP command register must be written to twice always. (interrupts read the status register and VDP register accesses are sequence sensitive)

# **Appendix B - Input/Output Ports**



Sega Mk3 Hardware Reference Manual (Rev1) Page 31

# Appendix C - Sample Code to Read Gun

1:						
2:						
3:		CDATA	EQU	0C100H		; Gun Status Work (1)
4:		HVCNT	~	CDATA+1		; RAM Save Counter (1)
5:		HVDATA	EQU	HVCNT+1		; V.H Counter Save Work (40H)
6:		GCHKCT	EQU	HVDATA+0	40H	H ; (1)
7:		GCHKWK	EOU	GCHKCT+1		; (10)
8:		SHOOTF		GCHKWK+1		; Gun Shot Flag (1)
9:		HPOSI	EQU	SHOOTF+1		; H.Position Data (1)
			~			
10:		VPOSI	EQU	HPOSI+1		; V.Position Data (1)
11:		SWDATA	EQU	VPOSI+1		; Switch Data (2)
12:						
13:						
14:						
15:						
16:						
						;
18:	-					;
19:	;	* * * * * *	GUN SH	OOT ADDRE	SS	SEARCH **** ;
20:	;					;
21:	;======	========	========	==========	===	;
22:						
23:	GUNS::					
24:		LD	HL, HVCN	г		
25:		LD	DE, HVDA			
26:		LD	C,32	IA		
	GIDIG1		C, 3Z			
	GUNS1::		- /	_ 、		
28:		LD	A,(CDAT	A)	;	Color Data Flag Work
29:		DEC	A			
30:		RET	NZ			
31:	GUNSPP:					
32:		IN	A,(0DDH	)		
33:		AND	040H	,	: 1	bit 6, a Player 1 Pulse
34:		JP	NZ,GUNS	מס		wait for low
				FF	'	walt for fow
35:		LD	A,(HL)			
36:		CP	С			
37:		JR	NC,GUNS	PP		
38:		INC	(HL)		;	Counter Up
39:		IN	A,(07FH	)	;	H.Counter Read
40:		LD	(DE),A		;	RAM Save
41:		INC	DE			
42:		IN	A,(07EH	)	; •	V.Counter Read
43:		LD	(DE),A	/		RAM Save
					<i>'</i>	IAH SAVE
44:	a	INC	DE			
	GUNS2:					
46:		IN	A,(ODDH	)		
47:		AND	040H		; ]	bit 6
48:		JP	Z,GUNS2			
49:		JP	GUNSPP			
50:						

51: ;======; 52: ; \*\*\*\*\* V & H DATA CHECK \*\*\*\*\* ; 53: ;======; 54: GUNCHK:: LD A,(SHOOTF) ; Gun Shoot Flag 55: 56: OR А 57: RET Z XOR 58: А 59: LD (SHOOTF),A 60: GUNCHKTI: LD 61: A,(HVCNT) ; V & H Counter 62: CP 5 63: RET С 64: ; DEC 65: А 66: LD B,A 67: LD HL, HVDATA+1 68: LD E,OH 69: GUNNCH: A,(HL) ; V.Counter 70: LDINC Е 71: 72: LD C,A 73: INC HL74: INC HL75: XOR А 76: LD A,(HL) 77: SUB С 78: CP 3 79: CALL NC,GCWKL2 80: GUNNCH DINZ 81: GCHKL2 CALL 82: ; CALL CHGN 83: 84: ; 85: LD A,(HL) ; H-COUNTER READ 86: CP 0A0H 87: RET NC 88: A,A ; CARRY FLAG = CLEAR AND 89: SUB 016H ; A=A-14H 90: ; 016H-004H :Right ?? ????? 91: ;SUB 91: ;SUB 016H-004H :Right ?? ???? 92: ;SUB 016H+004H :Left ?? ???? 93: ; 94: SLA А ; A=A\*2 95: LD B,A 96: REPT 5 97: RRA 98: ENDM 99: AND А,07Н ; CARRY FLAG = CLEAR 100: ADD в ; A=A+A/16 (HPOSI),A 101: LD 102: INC HLA,(HL) 103: LD ; V.Counter Read 104: AND ; CARRY FLAG = CLEAR A,A . 018H ; A=A-18H 105: ;SUB SUB 001H 106: (VPOSI),A 107: LD \* Color Data Set \* 108: ; ; XOR A 109: (0BFH),A 110: OUT 111: LD A,OCOH 112: OUT (OBFH),A 113: LD BC,020BEH 114: LD HL,COLORTBL ; Color Data Table 115: OTIR 116: RET 117: COLORTBL: 118: DEFB 119: DEFB 120: DEFB 121: DEFB 122: 123: 124:

125: 126: 127:	GCHKL2:		
128: 129: 130:	Genitiz.	PUSH LD LD	HL HL,GCHKCT A,(HL)
131:		CP	5
132:		JP	NC,GCHL1
133: 134:		INC LD	(HL) HL,GCHKWK
135:		PUSH	DE
136:		LD	D,0
137: 138:		LD ADD	E,A HL,DE
139:		POP	DE
140: 141:	GCHL1:	LD	(HL),E
142:	GCIIIII.	POP	HL
143:		LD	Е,ОН
144: 145:	;	RET	
146:	,		
	CHGGN:		
148: 149:		LD JP	A,(HL) CHGN4
150:	;	0F	CHGN4
	CHGN:		
152: 153:		LD LD	HL,GCHKWK C,O
154:		LD	A, (GCHKCT)
155: 156:		CP	1
150.		JP LD	Z , CHGGN B , A
	CHGN1:		
159: 160:	CHGN2:	LD	A,(HL)
161:	01101112	INC	HL
162: 163:		CP	(HL)
164:		JP DJNZ	C,CHGN3 CHGN2
165:		JP	CHGN4
166: 167:	CHGN3:	INC	С
168:		DJNZ	CHGN1
	CHGN4:		
170: 171:		RRCA AND	07FH
172:		LD	B,C
173:		LD	C,A
174: 175:		LD OR	A , B A
176:		JP	Z,CHGN6
177: 178:		LD	HL,GCHKWK
179:	CHGN5:	XOR	A
180:		ADD	A,(HL)
181: 182:		DJNZ ADD	CHGN5 A,C
183:	CHGN7:	1100	11,0
184:		ADD	Α,Α
185: 186:		LD LD	С,А В,О
187:		LD	HL, HVDATA
188:		ADD	HL,BC
189: 190:	CHGN6:	RET	
191:	5110110	LD	A,C
192:		JP	CHGN7
193: 194:			
195:			
196:			

197: ;======;; 198: ; ; \*\*\*\*\* GUN CHECK \*\*\*\*\* ; . 199: ; 200: ; 201: ;=======;; 202: GUNINT:: GUNINT:: LD HL,CDATA ; Flash States Work LD A,(HL) LD (HL),2 ; DEC A ; CP 1 RET Z ;(CDATA)=1 ---> (CDA LD (HL),0 ; DEC A ; CP 2 RET Z ;(CDATA)=2 ---> (CDA . 203: ; ; CP 1 ;(CDATA)=1 ---> (CDATA)=2 , RET ; 204: 205: 206: 207: 208: 209: ;(CDATA)=2 ---> (CDATA)=0 , RET 210: 211: ; CALL SWSET 212: ; bit 4 ;(CDATA)=0 , TRI.=OFF ---> RET AND 010H RET Z 213: 214: 215: ; XOR A 216: XOR A LD (HVCNT),A LD A,1 ; A.res = 1 LD (CDATA),A ;(CDATA)=0, TRI.=ON ---> (CDATA)=1, RET LD (SHOOTF),A ; Gun Shoot Flag Set 217: 218: 219: 220: 221: ; \* Screen Flash XOR A OUT (0BFH),A LD A,0C0H OUT (0BFH),A LD A,03FH OUT (0BEH),A \* RAM Clear \* 222: 223: 224: 225: 226: 227: 228: ; \* RAM Clear \* LD HL, HVCNT 229: LD DE,HVCNT+1 LD BC,001H+040H+001H+10 LD (HL),0 230: 231: 232: 233: LDIR 234: RET 235: 236: 237: 238:

: ;=====			======	=====;
): ;				;
: ;				;
;				;
;=====			=====	=====;
;				;
;		1.0.1.0	now	i
;		CPL		i
;		0.1.0.1	now	;
;		1.1.0.0	old	;
;		AND		;
		0.1.0.0		;
		CPL		;
		1.0.1.1		;
;===== SWSET:			=====	=====;
	IN	A,(ODCH)		;
	AND	010H		; bit 4
	LD	HL,SWDATA		; Switch data save area
	CPL			
	LD	C,A		; Data save
	XOR	(HL)		
	LD	(HL),C		; New SW.data save
	INC	HL		
	AND	С		; ACC : '0'> '1' change but data
	LD	(HL),A		; Data save
	RET	. ,,		
				=====;
; ; = = = = = =		iterrupt Jump C		** ; ======;
ORG	038H			
	PUSH	AF		
	LD	A, (CDATA)		; Gun Set ?
	DEC	Α		
	JR	NZ,INSS		
	EX	(SP),HL		; Stack Pointer Change
	POP	HL		;
	LD	HL,GUNS1		;
	EX	(SP),HL		;
	PUSH	AF		'
INSS:	FUBII	лı,		
	POP	AF		
	JP	INT38		
	01	THIJO		

# Appendix D - Sample Code to Read Track Ball

	BALL SWIT			
	RET			CONDITION (-7FH ~ 7FH)
				CONDITION (-7FH ~ 7FH) CONDITION (-7FH ~ 7FH)
				2 CONDITION (-7FH ~ 7FH) 2 CONDITION (-7FH ~ 7FH)
	~~~~~~	~~~~~~~~	~~~~~~	
01D0' 01D0'		T_BAL TRACK		
01D0'	3E 0D	110101	LD	A,00001101B
01D2'	D3 3F		OUT	(PSWC),A
01D4' 01D6'	06 19 10 FE		LD DJNZ	В,25 \$
01D8'	DB DC		IN	A,(P1_SWPT)
01DA'	E6 0F		AND	OFH
			REPT RRCA	4
			ENDM	
01DC' 01DD'	OF OF	*	RRCA RRCA	
01DD' 01DE'	OF	*	RRCA	
01DF'	OF	*	RRCA	
01E0' 01E1'	57 3E 2D		LD	D,A > 00101101B
01E1 01E3'	D3 3F		LD OUT	A,00101101B (PSWC),A
01E5'	06 0D		LD	В,13
01E7' 01E9'	10 FE DB DC		DJNZ IN	\$ A,(P1_SWPT)
01E9 01EB'	E6 OF		AND	OFH
01ED'	В2		OR	D
01EE' 01F0'	ED 44 32 C018		NEG LD	(P1_TRX),A
01F3'	52 0010	TRACK		(22_100)/11
01F3'	3E OD		LD	A,00001101B
01F5' 01F7'	D3 3F 06 0D		OUT LD	(PSWC),A B,13
01F9'	10 FE		DJNZ	\$
01FB' 01FD'	DB DC E6 0F		IN AND	A,(P1_SWPT) OFH
UIID	10 01		REPT	4
			RRCA	
01FF'	OF	*	ENDM RRCA	
0200'	OF	*	RRCA	
0201'	0F	*	RRCA	
0202' 0203'	0F 57	^	RRCA LD	D,A
0204'	3E 2D		LD	A,00101101B
0206'	D3 3F		OUT	(PSWC),A B,13
0208' 020A'	06 OD 10 FE		LD DJNZ	\$
020C'	DB DC		IN	A,(P1_SWPT)
020E' 0210'	E6 OF B2		AND OR	0FH D
0210	ED 44		NEG	D
0213'	32 C019		LD	(P1_TRY),A
0216' 0216'	3E 07	TRACK	_X2: LD	A,00000111B
0218'	D3 3F		OUT	(PSWC),A
021A' 021C'	06 19 10 FE		LD DJNZ	В,25 \$
021C' 021E'	DB DC		IN	A,(P1_SWPT)
0220'	E6 C0		AND	1100000B
0222' 0223'	0F 0F		RRCA RRCA	
0223	5F		LD	E,A
0225'	DB DD		IN	A,(P2_SWPT)
0227' 0229'	E6 03 0F		AND RRCA	11B
022A'	OF		RRCA	

Sega Mk3 Hardware Reference Manual (Rev1) Page 37

77:				
78:	022B'	83	OR	E
79:	022C'	57	LD	D,A
80:	022D'	3E 87	LD	A,10000111B
81:	022F'	D3 3F	OUT	(PSWC),A
82:	0231'	06 0D	LD	в,13
83:	0233'	10 FE	DJNZ	\$
84:	0235'	DB DC	IN	A,(P1_SWPT)
85:	0237'	E6 C0	AND	11000000B
86:	0239'	5F	LD	E,A
87: 88:	023A' 023C'	DB DD E6 03	IN AND	A,(P2_SWPT) 11B
89:	023E'	B3	OR	E
90:	023F'	07	RLCA	<b>1</b>
91:	0240'	07	RLCA	
92:	0241'	В2	OR	D
93:	0242'	ED 44	NEG	
94:	0244'	32 C01A	LD	(P2_TRX),A
95:	0247'		TRACK_Y2:	
96:	0247'	3E 07	LD	A,00000111B
97:	0249'	D3 3F	OUT	(PSWC),A
98:	024B'	06 19	LD	в,25
99: 100:	024D'	10 FE DB DC	DJNZ	\$
100:	024F' 0251'	E6 C0	IN AND	A,(P1_SWPT) 11000000B
101:	0251	OF	RRCA	TIOOOOOD
103:	0254'	0F	RRCA	
104:	0255'	5F	LD	E,A
105:	0256'	DB DD	IN	A,(P2_SWPT)
106:	0258'	E6 03	AND	11B
107:	025A'	OF	RRCA	
108:	025B'	OF	RRCA	
109:	025C'	B3	OR	E
110:	025D'	57	LD	D,A
111:	025E'	3E 87	LD	A,10000111B
112: 113:	0260' 0262'	D3 3F 06 0D	OUT LD	(PSWC),A B,13
114:	0264'	10 FE	DJNZ	\$
115:	0266'	DB DC	IN	A,(P1_SWPT)
116:	0268'	E6 C0	AND	11000000B
117:	026A'	5E	LD	E,A
118:	026B'	DB DD	IN	A,(P2_SWPT)
119:	026D'	E6 03	AND	11B
120:	026F'	в3	OR	E
121:	0270'	07	RLCA	
122:	0271'	07	RLCA	
123:	0272'	B2	OR	D
124:	0273'	ED 44	NEG	
125: 126:	0275' 0278'	32 C01B C9	LD RET	(P2_TRY),A
126.	02/0	69	KE1	
121.				

# **Developer's Notes**

(1) Z80 - Memory Map
(_,
Frame 3
 ++ \$C000
+ \$8000
Frame 1   \$FFFE
++ \$4000
++ \$0000
++ \$0000
(2) Memory Control Registers
* \$FFFF - Frame 2 Control Register
msb lsb
+++++++
++ROM Page Number for Frame 2
* \$FFFE - Frame 1 Control Register
msb lsb
++++++++ +++ ROM Page Number for Frame 1
* \$FFFD - Frame 0 Control Register
msb lsb ++++++
++ROM Page Number for Frame 0
* \$FFFC - Frame 2 RAM Control Register
msb 7 4 3 2 1 0 lsb
+++++++
+ Bank Number Shift     + Ext RAM Bank Number
+ ROM/RAM SW. 0=ROM, 1=RAM + RAM Write Protect Sw.?
+ Dev Brd Write Protect Sw.?
NOTE: When power is applied, the following data is set by the system ROM program
\$FFFF = 2
Bit 7 of \$FFFC is write protect bit for ROM Board (Just for development board only
0 = R/W 1 = Read Only

#### (3) The 4M Bit ROM

\$80000	-++	++-	++-	++		
	\$1F	\$17	\$0F	\$07	< Bank Number	
					The address which is set by Bank Shift 00 and Bank Number 09 can	
-  \$60000	\$19	\$11	\$09	\$01	also be accessed by	
	++   \$18	++	++   \$08	++	Bank Shift 01 and Bank Number 1.	
	\$17   ++	\$0F   ++	\$07   ++	\$1F   ++		
	++   \$11	++   \$09	++   \$01	++   \$19		
\$40000	++   \$10	++	++	++		
	\$0F   ++	\$07   ++	\$1F   ++	\$17   ++		
\$20000	\$09	\$01	\$19	\$11		
	\$08	\$00	\$18	\$10		
	\$07   ++	\$1F   ++	\$17	\$0F   ++		
	\$01	\$19	\$11	\$09		
\$00000	++   \$00   -++	\$18   ++-	++   \$10   ++-	++   \$08   ++		
	00		01	10	<pre>11 &lt; Bits 0 &amp; 1 of \$FFFC (Bank Number Shift)</pre>	

(4) Z80 Address \$0000 - \$03FF

The lower 1K (1024 bytes) of the Z80 address range is always mapped to the lower 1K (1024 bytes) of ROM to ensure that the reset and interrupt vectors are always available.

For example, if Bank #8 (ROM Address \$20000 - \$24000) were assigned to Frame 0 (Z80 Address \$0000 - \$4000) then ROM Address \$20000 - \$203FF cannot be accessed as Z80 Address \$0000 - \$03FF remains mapped to ROM Address \$00000 - \$003FF.

# **Supporting Illustrations**

